




BFLEX.FRONT/1 MODULAR

BARRIERA SINGOLA FRONTALE MODULARE
FRONTAL SINGLE BARRIER MODULAR









BFLEX.FRONT/1 MODULAR

ISTRUZIONI DI INSTALLAZIONE
ASSEMBLY INSTRUCTIONS



WARNING

The distance of installation depends on speed and weight of vehicle



BFLEX.FRONT/1 MODULAR

ISTRUZIONI DI INSTALLAZIONE
ASSEMBLY INSTRUCTIONS

