


03. GUARD RAIL

GR 90

BARRIERA SINGOLA
SINGLE-RAIL BARRIER



GR 90



ISTRUZIONI DI INSTALLAZIONE ASSEMBLY INSTRUCTIONS

WITH EXPANSION SCREW



M16 GALVANISED STEEL

Ø16 mm



WARNING


The distance of installation depends on speed and weight of vehicle

WALL


MIN 100mm*




1




2



3



4









GR 90

ISTRUZIONI DI INSTALLAZIONE
ASSEMBLY INSTRUCTIONS



M16 GALVANISED STEEL

WITH EXPANSION SCREW



GR 90

ISTRUZIONI DI INSTALLAZIONE ASSEMBLY INSTRUCTIONS



SF16 INOX



ANCHOR (FR)


WITH RESIN

CHEMICAL
ANCHOR

Ø18 mm




24




WARNING


The distance of installation depends
on speed and weight of vehicle




1




2



3



4



GR 90

ISTRUZIONI DI INSTALLAZIONE
ASSEMBLY INSTRUCTIONS



SF16 INOX



ANCHOR (FR)

WITH RESIN

